

BAIT GUN OPERATION MANUAL

A. Feature of Product

1. Prevent the Gel flow during use.
2. Use a fixed quantity to reduce expenses and protect environment.
3. Possible to control capacity according to Cockroach's numbers and types.

B. Operation Procedure

1. Push the Plunger Rod of the Bait Gun inside the Syringe by 1-1.5cm.
2. Insert Plunger Head obliquely into the Syringe to evacuate air in between the space.
3. Push the Plunger Rod smoothly until the Plunger Head reach to the set the base of Syringe to the Bait Gun.
4. Remove the Syringe Tip and pull the Trigger smoothly.
5. Check the Gel amount and reset the Gel Control Stopper if needed.
6. Take reverse procedure when needed to separate the Bait Gun from the Syringe.



Operation Manual of Gel Control Stopper

Set the Stopper position by adjusting bolt and nut on Stopper.

1. Left Side (marked by L) : When 1-2 Cockroaches are found.
2. Middle (center) : When many Cockroaches are found.
3. Right Side (marked by H) : When big Cockroaches are found.(American Cockroaches)

C. Caution to use

1. Use the Bait Gun smoothly with proper strength.
2. The O Ring size is different depending on the Syringe. It prevents the Gel flow and the Piston pulled out.

D. Part List

